

No	Borja	ITMY	Borja	ITMX	Borja	ETMY	Borja	ETMX
1	501.5576	501.554	502.7878	502.7854	503.6789	503.6788	507.3624	507.36
2	501.6332	501.624	502.9102	502.909	503.7371	503.7344	507.4959	507.493
3	501.6953	501.6937	504.1471	504.145	505.0803	505.0794	508.8461	508.844
4	503.0867	503.085	504.1804	504.1786	505.1892	505.186	508.9414	508.938
5	503.1988	503.198	504.7205	504.719	510.7162	510.715	511.3029	511.2993
6	501.7584	501.755	504.8534	504.85	510.7275	510.7264	516.6832	516.678
7			504.8918	504.891	513.4085	513.405	516.7830	516.781
8					513.5144	513.511		

Borja (remaining
modes)

	ITMY	ITMX	ETMX
504.6081	501.668	501.606	508.922
504.8864	501.628	501.8856	510.714
504.9531	501.953		511.18