

| Orders of magnitude of attenuation of cross-talk to adjacent channels (PEM Endeavco boxes at Corner Station) |               |
|--|---------------|
| Channel  | At saturation |
| New Endeavco 2 Channel 1   | 2             |
| New Endeavco 2 Channel 2   | 2             |
| New Endeavco 2 Channel 3   | 2             |
| New Endeavco 2 Channel 4   | 2             |
| New Endeavco 2 Channel 5   | 2             |
| New Endeavco 2 Channel 6   | 2             |
| New Endeavco 2 Channel 7   | 2             |
| New Endeavco 2 Channel 8   | 2             |
| New Endeavco 2 Channel 9   | 2             |
| New Endeavco 2 Channel 10  | 2             |
| New Endeavco 2 Channel 11  | 2             |
| New Endeavco 2 Channel 12  | 2             |
| New Endeavco 2 Channel 13  | 2             |
| New Endeavco 2 Channel 14  | 2             |
| New Endeavco 2 Channel 15  | 2             |
| New Endeavco 2 Channel 16  | 2             |