




DARM: excess noise during the injections shown below





Sensor showing Y-axis injections



Sensor showing X-axis injections



DARM. Red:
during first Y-
axis injection
on previous
page, Black:
nominal.



**Motion
sensors at
stages 0, 1, 2
(counterclock
wise)**

