
Transfer function: (IOP\−SUSEY_MDAC4_TP_CH4) / (ETMY_L3_ESDOUTF_LL_OUT)
Magnitude
Measured
Expected
Discrepancy: (measured)/(expected)
Magnitude
FIR uncorrected
FIR corrected
Phase [deg]
Frequency [Hz]
Phase [deg]
Frequency [Hz]